

## **Time Clock Mounting Template**

Use this template to mount your time clock.

Where do you want your time clock to display? Line up this handy template on your wall and drill holes through the targets using a 1/4" (6.35mm) drill bit. Insert the provided drywall anchors, if needed, and screw the mount to the wall using the provided screws. Hang your time clock on the mount.